

Bike Rack Installation Instructions from BA Steel

1. Place rack in area required.
2. Drill into box section with holes.
3. Drill with 10mm masonry drill bit.
4. Insert 10mm straight anchor bolts approx. 100mm long.
5. Tighten the nuts according.
6. Cut of excess threads to avoid any trip hazards.

If you have any questions regarding the installation of your bike racks please feel free to contact Brian Arkins on 0862415606 anytime.